

Congratulations! You are now the proud owner of your very own

dopen[®]



Here's how to use it



Engage Cartridge



Turn on DOPEN

Push button 5 times



Select Temperature

Push button 3 times to change temperature



Use your DOPEN

After selecting temperature push and hold button while inhaling slowly



Charge your DOPEN

Swing bottom cap to reveal USB charge port.
Compatible with included USB charger.



Follow us on instagram! @wewantdope

Tag your DOPEN pics! #wewantdope

Your DOPEN is built to last. With proper handling, storage and use, you can expect years of trouble free vaping.

Please refer to these simple tips to keep your DOPEN working flawlessly.

Other Light Functions:

White Light: Indicates a connection issue with the cartridge. Try turning the cartridge back a half a turn after attaching the cartridge to the battery. If this doesn't work you can slightly lift the connection plate on the cartridge (small circular piece at the base of cartridge threading) using small flat tool.

Purple Light: Indicates a programming issue. Try to reset the chip by running the battery through three on/off cycles.

Battery Capacity: 650 mAH

Micro USB charger: Light will shine red when battery is not fully charged and turn off when battery is fully charged. When you attach the battery to the charger it will automatically put the battery in the off setting. You will have to press the button five times rapidly again to turn the device back on.


Troubleshooting advice:

The main issue on these batteries stems from leaking cartridges. Be sure to periodically clean the connection plates (small circular piece by threading on both battery and cartridge) with a q-tip dipped in isopropyl alcohol. If your cartridge is leaking it becomes possible that oil will get into the battery. It is advisable to switch cartridges as this can cause issues with the battery's ability to function.

USB Slide Cover should be in the closed position when not charging battery. Failure to do this could cause irreversible damage to the USB Slide Cover. Magnets will have difficulty connecting if surface is dirty. These can also be cleaned using a q-tip dipped in alcohol and are located on both sides of top connection and middle connection.

You may find not all cartridges will fit with the magnetic sleeve attached. Be sure to double check other brand cartridges before purchasing. This goes for both the width and the height as mouthpieces may not reach out far enough to be used with middle sleeve attached. We can only guarantee the functionality of DOPE Oil Cartridges.

The following DOPEN components are covered by a six month warranty.



Normal wear and tear, scratches, drops, oil and water damage are not covered.

If you need warranty service, please do not contact the store where you purchased your DOPEN. All claims will be handled by contacting info@wewantdope.com

Please note: a dated copy of your receipt will be needed for the warranty claims